

Accurate

TECHNOLOGY INC.

Linear Digital Measuring Systems

DIGI LCD Readout



Firmware Version d 2.100 & higher

Installation & Operation

READOUT SERIAL # _____

SCALE SERIAL # _____

TO MAXIMIZE THE ACCURACY OF YOUR SYSTEM, THE FOLLOWING PROGRAMMING PARAMETER HAS BEEN PRE-CONFIGURED AT THE FACTORY FOR THIS READOUT AND SCALE COMBINATION:

PARAMETER 13 (Linear Multiplier) _____

WARRANTY

Accurate Technology, Inc. warrants this product against defective parts and workmanship for 1 year commencing from the date of original purchase. Upon notification of a defect, Accurate Technology, Inc., shall have the option to repair or replace any defective part. Such services shall be the customer's sole and exclusive remedy. Expenses incidental to repair, maintenance, or replacement under warranty, including those for labor and material, shall be borne by Accurate Technology, Inc. (Including freight or transportation charges during the first 30 days).

Except as expressly provided in this warranty, Accurate Technology, Inc. does not make any warranties with respect to the product, either expressed or implied, including implied warranties of merchantability or fitness for a particular purpose, except as expressly provided in this agreement.

Accurate Technology, Inc. shall not be liable for any special, incidental, or consequential damages or for loss, damage or expense directly or indirectly arising from the customer's use of or inability to use the equipment either separately or in combination with other equipment, or for personal injury or loss or destruction of other property, or from any other cause.

To request repair work, (either warranty qualified parts or not) contact Accurate Technology, Inc. directly by phone, fax, or e-mail. A Returned Merchandise Authorization (RMA) number is required before returning a product for repair.

Accurate Technology, Inc.

+1 828.654.7920 800.233.0580 828.654.8824 (F)

www.proscale.com

info@accurate-technology.com

SAFETY WARNING

**Before installing this product on any machinery:
Turn off machine and disconnect power.**

SAFETY WARNING

P/N 800-1101-001 Rev 06012014

Copyright © 2014 All rights reserved

Table of Contents

SECTION 1	GENERAL INFORMATION	5
	INTRODUCTION	5
	WHAT THIS MANUAL INCLUDES	5
	SPECIFICATIONS	5
	MOUNTING THE READOUT	6
	CHANGING BATTERY	6
SECTION 2	OPERATION	7
	READOUT KEYS	7
	Key Timing	7
	On/Off Key	7
	Units Key	7
	+, DATUM, and - Key	8
	REVERSE READINGS	8
	READOUT LOCK MODE	9
	READOUT RESOLUTION	9
	MEASUREMENT UNITS	9
	AUTO ON/OFF	10
	LINEAR SCALING	10
	MAKING INCREMENTAL MEASUREMENTS	10
	CIRCUIT BOARD JUMPERS	11
	READOUT PROGRAMMING	12
	PROGRAMMING PARAMETERS	13
	FREQUENTLY ASKED QUESTIONS	15

Introduction

This Digital Readout, (DRO), is one of two available from Accurate Technology for use with DIGI Family measuring systems.

The following pages describe the set-up and operation of the **Digi LCD Readout** when used with DIGI Family products.

What This Manual Includes

This manual includes information for:

Digital Readout, LCD, DIGI
Part Number: 700-1600-D55
Firmware Version d 2.100 & higher

Specifications

Resolution	.1inch .1mm or .01inch .01mm or .001inch .01mm or 1/16, 1/32 or 1/64 inch
Repeatability:	.001inch or .01mm
Readout Range:	± 999.999 in; $\pm 399 \frac{63}{64}$ in; ± 9999.99 mm
Operating Power:	1 CR123 Lithium Battery.
Operating Temp:	40 to 110°F


This Product was MADE IN USA

Mounting the Readout

Consult the [Installation](#) document you received for installation of other components of your measuring system.

The DIGI Digital Readout may be mounted:

- Using Velcro or Double sided tape
- Drilling out the 3 holes from the inside of the case
- Using any of the six holes on the back of the case which may tapped for M2 or 4-40 screws.




Changing the Battery

A low battery indicator will appear in the lower left corner of the LCD. When battery voltage drops below approximately 2.6V the readout will turn itself off until the battery is replaced.



To replace the battery remove the screws in the upper right and lower left corners. Pull the cover off. Remove the old battery and install a new CR1233 (or equivalent) Lithium battery. Replace the cover and tighten the screws.



Readout Keys



Key Timing

The keys pictured above, are found on all Digi readouts, and some of them have multiple functions.

Timing, which is how long a key is depressed, and the combination of the keys pressed is important. This manual uses the term “*momentarily*” to describe a key press of shorter than 1 second. Whereas the term “*press and hold*” is used to describe a key press of longer than 1.5 seconds. As an example; when using a PC keyboard to type a capital letter you would “*press and hold*” the SHIFT key and “*momentarily* depress the LETTER key. In addition most of the key “*functions*” are executed on RELEASE, not press. This is important since some of the same keys execute different functions based on how long they are pressed and when they are released. These key operations, once tried will quickly become intuitive.

On/Off Key

Momentarily pressing the **ON/OFF** key will cause the readout to turn on or off. The Firmware Version of the readout is displayed on power-up when **ON/OFF** key is used. While the readout is on, if the encoder is not moved for 15 minutes, the readout will automatically turn itself off to conserve battery life. While it is off if the encoder is moved as little as .002in (.05mm), or the **ON/OFF** button is pressed, the readout will automatically turn itself back on with no loss of position.

Units Key

The readout can display position information in decimal inches, fractions, or millimeters. To change the current display mode, momentarily press the **UNITS** key. With each key press the readout will cycle through decimal inches, fractional inches and millimeters.

When the readout is in 1/16 or 1/32 inch fraction mode, a series of “bars” in the upper right corner of the display, each representing 1/64th of an inch, may appear. (ie. When in 1/16 inch mode and three bars are showing, the measurement displayed is rounded *down* to the closest 1/16 inch and each illuminated bar indicates an additional 1/64 of an inch of measurement.) For

better resolution, switch to 1/32 or 1/64 mode. For the best resolution and accuracy switch to a decimal mode – inches or millimeters..



When the measurement is greater than 99 63/64 inches, a **+100** and/or **+200** will illuminate in the upper right portion of the display to indicate this amount must be added to the displayed reading. ie: If the measurement is 154 5/8 inches, 54 5/8 and **+100** will be illuminated on the display. If the measurement is -307 23/64 inches, - 7 23/64, **+100** and **+200** will be illuminated on the display.

+, DATUM, and - Key

The **+** (plus), **DATUM** and **-** (minus) keys are used to change the currently displayed position to a different value. The **DATUM** key forces the readout to display a user programmed value. Programming Parameter Pr1

Momentarily depressing the **+** key increments the current position by one unit of measurement. Momentarily depressing the **-** key decrements the current position by one unit. Pressing and holding the **+** or **-** keys will cause the displayed position to change continuously. Holding down the key will cause the amount of change to speed up. This allows for quick adjustments over a range of large values.

NOTE: While the **DATUM** key can be used to simply “zero” the currently displayed value, it can also be programmed to force the readout to a preset value. This can be zero, or any other displayable value.

See Section 3: Readout Programming, **Programming Parameter Pr1**.

Reverse Readings

Reverse readings means changing the direction of readings produced by moving the encoder. If the readout decrements (reduces or goes negative) when it should be incrementing (increasing or going positive), the readout will need to be re-programmed for your application.

See **Programming Parameter Pr2**.

Readout Lock Mode

To activate the Lock function Press and hold the **ON/OFF** key and then momentarily press the **UNITS** key. The word **LOCK** will appear in the upper left corner of the readout. When **LOCK** is displayed, the **+**, **DATUM** and **-** keys become inactive to prevent accidental changes of the (calibrated) current displayed position. To de-activate the Lock function, press and hold the **ON/OFF** key and then momentarily press the **UNITS** key.

NOTE: The Lock function can also be enabled/disabled through programming. This allows a more permanent Lock function since programming can be disabled with a hardware jumper inside the readout thus preventing any front panel programming changes.

See **Programming Parameter Pr3**.

Readout Resolution

The readout can be configured to display measurements in any of three different resolutions.

1. Low– the resolution is .1in or .1mm.
2. Normal– the resolution is: .01in or .01mm.
3. High– the resolution is: .001in or .01mm

The display of fractions remains the same for all settings: 1/16, 1/32 & 1/64

See **Programming Parameter Pr4**.

Measurement Units

The measurement units displayed on the Readout are user configurable. The table below provides a matrix for selecting the measurement units that may be displayed when pressing the **UNITS** key.

See **Programming Parameter Pr11**

Programming Parameter Pr 11 Value	Measurement Units Displayed
0	All inch units, and millimeters
1	Millimeters only
2	Decimal inches and millimeters
3	Decimal inches and centimeters
4	All inch units, and centimeters
5	Centimeters only
6	Decimal inches only

Auto on/off

To prolong battery life, the Readout has a built-in function that turns off the Readout after a period of no movement or key activity. The Auto On/Off function is programmable from 0 (always on), to 240 (minutes) before entering sleep mode.

Press the **ON/OFF** key or move the measurement system to wake up the Readout. Any key press or system motion while the Readout is awake restarts the Auto On/Off timer.

See *Programming Parameter Pr12*

Linear Scaling

This function is useful for maximizing the accuracy of your system or when the actual measurement or position must be multiplied or divided before being displayed on the Readout.

This function has a range of 0.0001 to 9.9999 allowing the actual measured value to be multiplied or divided in very small or very large increments.

See *Programming Parameter Pr13*.

Use care when enabling this function. It will force the readout to display a value different from the actual measurement or position.

Making Incremental Measurements

The readout has two measurement modes, or indexes. One is referred to as **ABS** or Absolute, and the other as **INC**, or Incremental. The absolute measurement mode allows the operator to read the current position of the encoder referenced from a fixed or known position-usually zero.

The incremental mode allows the operator to make relative distance measurements from one arbitrary point to another. The absolute position of the DigiScale is not lost when using the incremental mode.

Absolute The readout automatically enters ABS mode when power is first applied. This is indicated by the **ABS** symbol in the upper left corner of the display. While in the ABS mode, all encoder positions are related to the current ABS, or absolute system reference point.

Incremental To enter the INC mode, press and hold the **UNITS** key for approximately 3 seconds. The **INC** symbol will appear in the upper left corner of the display. When the INC mode is entered the readout will display zero (0) or the last offset if one was entered, and may be changed by using the + or - keys to provide a different offset. Moving the encoder in either direction will display the distance moved from the initial INC starting point (plus any offset).

To complete another incremental measurement from the new position, momentarily press the **UNITS** key. The readout will again change to 0 (or the previously programmed offset). To return to the ABS mode, press and hold the **UNITS** key for approximately 3 seconds.


NOTES: when the readout is in incremental measuring mode the **UNITS** key no longer functions to change the measurement units displayed.

The absolute position of the DigiScale is not lost when using the incremental mode. When the readout is switched back to the absolute mode the readout reflects the current encoder position relative to your original calibrated absolute setting.

Circuit Board Jumpers

The Digi readout has several user configurable jumpers consisting of three pins and a 'shorting block or jumper'.

The center of these three pins is 'Common'. One end pin is labeled **A** and the other end pin is labeled **B**.




JP1
JP2

FACTORY USE ONLY
Programming Lockout
Position **A**, Front Panel Programming is **ENABLED**
Position **B**, Front Panel Programming is **DISABLED**

Readout Programming

Several functions of the Digi readout is user programmable. The following describes what features and functions are available and how to change the factory defaults to customize your DigiScale system.

To enter Programming Mode:



1. Press and hold the **UNITS** key then momentarily press the **DATUM** key.
2. The LCD will briefly display: **PG on** (Programming On), then **Pr 1**, (indicating Programming Parameter #1)
3. Release the **UNITS** key
4. The value stored in **Pr1** is displayed.

Once in the Programming Mode:

Moving up parameter list - Momentarily press the **UNITS** key to advance through the Programming Parameter list, first displaying the Programming Parameter number then the currently programmed value.

Moving down parameter list - Press and hold the **ON/OFF** key and momentarily press the **UNITS** key to move backward through the Programming list.

Increase parameter value - Momentarily press the **PLUS (+)** key while displaying a Programming Parameter Value to increase the setting.

Decrease parameter value - Momentarily press the **MINUS (-)** key while displaying a Programming Parameter Value to decrease the setting.

Reset parameter value to default setting - Momentarily press the **DATUM** key while displaying a Programming Parameter Value to reset the parameter to the factory default value.

Exit programming mode - Press and hold the **UNITS** key. Momentarily depress the **DATUM** key. The LCD will briefly display: **PG off** (Programming Off), then return to normal operation. **NOTE:** The system will automatically exit programming mode after 60 seconds of no key activity.

Programming Parameters

The Digi readout programming parameters are listed below. Values in [] are the available range of values that can be entered for that parameter. Factory defaults are shown in **Bold Red**.

NOTE: Programming parameters are not sequentially numbered due to firmware differences between measurement systems and the provision for future enhancements, functions and custom features.

Pr 1 – Datum Key [0 to ± 999.999in] or [0 to ±9999.99mm]
The programmed value that will be recalled whenever the **DATUM** key is pressed during normal operation.
Default = 0.00

Pr 2 – Reverse Readings [0 or 1]
This parameter controls the direction of travel (positive vs. negative) when the encoder is moved.
Default = 0

Pr 3 – Key Lockout [0 or 1]
This parameter controls the operation of the **+**, **-** and **DATUM** keys. If enabled, (set to 1), these keys will not function and the **LOCK** symbol will appear on the display. This prevents accidental changes when pressing these keys during normal operation.
Default = 0

Pr 4 – Readout Resolution [1, 2, 3 or 4]
This parameter sets the number of places to the right of the decimal point on the readout.
A value of 1 – Low - will display x.x.
A value of 2 – Normal -will display x.xx
A value of 3 – High - will display x.xxx
Default = 2

NOTE:
Millimeters have a maximum of 2 places (even if parameter is set to 3.)
This setting has no effect when displaying fractions.

Pr11 – Readout Measurement Units [0 to 6]

This parameter controls the type of measuring units the Readout displays when the **UNITS** key is pressed. The table below illustrates the possible combinations of measuring units that will be displayed by changing this parameter.

Default Value = 0

Pr 11 Setting	Displayable Units
0	All inch units and millimeters
1	Millimeters only
2	Decimal inches and millimeters
3	Decimal inches and centimeters
4	All inch units and centimeters
5	Centimeters only
6	Decimal inches only

Pr12 – Readout Auto-Off Time [0 to 240]

This parameter changes the amount of time before the display turns off to conserve battery power. The value is the number of minutes of idle operation (no movement or key presses) before the display turns off. When this parameter is enabled ($\neq 0$), pressing the **ON/OFF** key or movement of the encoder or system will wake up the Readout.

A value of '0' disables the Auto Off feature (the Readout is always on).

Default Value = 15 (minutes)

Pr13 – Linear Compensation [0.00001 to 9.99999]

This parameter invokes a linear multiplier correction in the Readout that is applied to the actual measurement prior to any offsets. This adjusted measurement is then displayed on the Readout. This is useful, for instance, if you would like to display half, double, or other values that can be achieved by multiplying the actual measurement by the value of the parameter setting.

Default Value = 1.00000

Frequently Asked Questions

What F/W (Firmware) version do I have?

The display will show **d 2.xxx** on power up. This is the firmware version of your readout.

What does no Enc mean?

If the encoder is off the scale, or unplugged from the readout, a **no Enc** will appear on the readout. To clear the error:

1. Be sure the encoder is on the scale.
2. Plug the encoder into the readout.
3. Unplug the encoder from the readout for one second then reconnect it.

The keys don't seem to do what they are supposed to do.

Timing, which is how long a key is depressed, and the combination of the keys pressed is important. This manual uses the term "*momentarily*" to describe a key press of shorter than 1 second. Whereas the term "*press and hold*" is used to describe a key press of longer than 1.5 seconds. As an example; when using a PC keyboard to type a capital letter you would "*press and hold*" the SHIFT key and "*momentarily* depress the LETTER key. In addition most of the key "*functions*" are executed on RELEASE, not press. This is important since some of the same keys execute different functions based on how long they are pressed and when they are released. These key operations, once tried will quickly become intuitive.

The readings are "backwards"?

You can change the reading direction of the system by:

1. Reversing the orientation of the encoder on the scale.
2. Changing the value of **Programming Parameter Pr 2.**

What does b FAIL mean?

When the readout displays this message it means the battery voltage has dropped to a level where reliable operation is no longer possible. Install a new battery to clear this message.

What does P FAIL mean?

When the readout displays this message it means the battery voltage has dropped to a level where reliable programming is not possible. Install a new battery to clear this message.

**Thank you for choosing an
AMERICAN MADE PRODUCT**



Accurate Technology, Inc.
270 Rutledge Rd. Unit E
Fletcher, NC 28732 USA
828.654.7920

Please register your product at:
www.proscale.com/registration.htm

This manual is available online at:
www.proscale.com

P/N 800-1101-001 Rev 06012014
Copyright © 2014 All rights reserved